



1012 South Creek View Court
Churchton, Maryland 20733
WWW.BEAUX-ARTES.COM

Phones: 410-867-0790
301-855-4244
FAX: 410-867-8004

RECESSED CHANDELIER INSTRUCTIONS FOR ATTACHING CRYSTALS

Install your decorative medallion before attaching your crystals. It is much easier to do; particularly the first time, without all your beautiful crystals on it. We have instructions and a video on our website showing our Two Minute Makeover for installing our medallions.

If you are using existing baffles, please check the springs which will be holding up your Recessed Chandelier. Two additional springs will be included for every chandelier, so please use them if they need to be replaced. Additional springs for the 2.5" and 3" tear drop crystals are recommended.

With your Recessed Chandelier installed you are now ready to hang all your crystals.



The crystals attach to the headpins on your Recessed Chandelier. If your Recessed Chandelier was ordered with a chain, it will have been attached to one of the headpins for you. In order to avoid broken crystals, there will be another headpin for each of the crystals.



Put the crystal hook into the headpin.

There is a front and back to the bowtie clasp. Make sure all your crystals are facing out so that you are looking at the front of the bowtie clasp.



Squeeze the hook down, locking the crystal into the headpin.

Examine the crystal to make sure it is hanging straight. The headpin and crystal bowtie clasp are easy to bend and shape so that your crystals are hanging perfectly straight.